














**IMPORTANT NOTICE:  
HARDWARE PACKAGE IS ATTACHED  
ON THE BOTTOM OF SEAT CUSHION.**

MODEL: B686

(1)X1  Back	(2)X1  Seat	(3)X1 (L)X1 (R)  Right & Left Arm
(4)X1  Mechanism	(5)X1  Gas Lift W/ Cover	(6)X1  Nylon Base
(7)X5  Casters	<p>(A)x4  M8x45 Arm Screw</p> <p>(B)x4  M8x22 Mechanism Screw</p> <p>(C)x4  M6x30 L-Bar Screw</p> <p>(D)x4  Arm Cap</p> <p>(E)x1  Allen Key</p>	



**Note: Please tighten all arm screws using allen key before step 6**

**Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using. This chair is only intended for sitting. Any other use will void the warranty.**

