












**IMPORTANT NOTICE:
HARDWARE PACKAGE IS ATTACHED
ON THE BOTTOM OF SEAT CUSHION.**

MODEL: B8401 B8801 B7201 B7206 HS350 B9831
 B7301 B8106 B8501 B7901 B7306 HS450 B9836
 B7906 B7701 B7706 B7641 B7741 HS1050 B7746
 B7501 B7506 B8101 B8506 B7601 B8316 B8221
 B8306 B7806 B8811 B7801 RC01 B7551

(1)x1  Back	(2)x1  Seat	(3)x1 (L)x1 (R)  Right & Left Arm
(4)x1  Mechanism	(5)x1  Gas Lift	(6)x1  Base
(7)x5  Casters	<p>(A)*8  M6*18 ARM SCREW</p> <p>(B)*8  ARM CAP</p> <p>(C)*4  M8*22 MECHANISM SCREW</p>	



Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using. This chair is only intended for sitting. Any other use will void the warranty.

