
IMPORTANT NOTICE: HARDWARE PACKAGE IS ATTACHED ON THE BOTTOM OF SEAT CUSHION.

MODEL: B16533C

(1)X1	(2)X1			(3)X1 (L)x1 (R)	
			→		
BACK	SEAT			ARM	
(4)X1	(5)X1			(6)X5	
			9		
GAS LIFT	BASE			CASTERS	
(7)X1			10		
	(A)X4	(jumin	M6*22	MECHANISM SCREW	
	(B)X4		M8*36	ARM SCREW	
	(C)X4	()	M6*30	L-BAR SCREW	
	(D)X4	(D)X4 (ARM CAPS	
MECHANISM	(E)X1 A		ALLEN	ALLEN KEY	



Note: Please tighten all arm screws using allen key before step 6

Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using. This chair is only intended for sitting. Any other use will void the warranty.



